









Edging Guide for Supreme COAT™ lens

Index	Edging Instruction
1.498 & 1.56	Use the provided transparent Anti-slippery sticker on both side. 









*ALL SWISSCOAT SupremeCOAT™ products (Rx and Stock lens) must strictly follow the above Edging Instruction.

Edging Guide for Supreme COAT™ lens

Index	Edging Instruction			
1.61	1st Cut	Convex Surface :	1st step : Use provided blue tape sticker	
		Concave Surface :	2nd Use provided transparent Anti-slippery sticker	
		Process :	1/ Increase the diameter on lens size in 6mm 2/ deblock the lens after first cut 3/ Replace the new transparent Anti-slippery on both side.	
	2nd Cut	Convex Surface :	Use transparent Anti-slippery sticker	
		Concave Surface :	Use transparent Anti-slippery sticker	
		Process :	Block the lens by holding with a plano lens on blocking machine.	
		Process :	Edge down to precise lens shape.	









*ALL SWISSCOAT SupremeCOAT™ products (Rx and Stock lens) must strictly follow the above Edging Instruction.

Edging Guide for Supreme COAT™ lens

Index	Edging Instruction			
1.67	1st Cut	Convex Surface :	1st step : Use provided blue tape sticker	
		Concave Surface :	2nd step : Use provided transparent Anti-slippery sticker	
		Process :	1/ Increase the diameter on lens size in 6mm 2/ deblock the lens after first cut 3/ Replace the new transparent Anti-slippery on both side.	
		*In case: the edge is thicker than 6mm	*Bevel the edge thickness to 1/3. (not more than 2.5mm inner from the edge)	
	2nd Cut	Convex Surface :	Use transparent Anti-slippery sticker	
		Concave Surface :	Use transparent Anti-slippery sticker	
		Process :	Block the lens by holding with a plano lens on blocking machine.	
		Process :	Edge down to precise lens shape.	

*ALL SWISSCOAT SupremeCOAT™ products (Rx and Stock lens) must strictly follow the above Edging Instruction.

Edging Guide for Supreme COAT™ lens

Index	Edging Instruction			
1.74	1st Cut	Convex Surface :	1st step : Use provided blue tape sticker	
		Concave Surface :	2nd step : Use provided transparent Anti-slippery sticker	
		Process :	1/ Increase the diameter on lens size in 6mm 2/ deblock the lens after first cut 3/ Replace the new transparent Anti-slippery on both side.	
		*In case: the edge is thicker than 6mm	*Bevel the edge thickness to 1/3. (not more than 2.5mm inner from the edge)	
	2nd Cut	Convex Surface :	Use transparent Anti-slippery sticker	
		Concave Surface :	Use transparent Anti-slippery sticker	
		Process :	Block the lens by holding with a plano lens on blocking machine.	
		Process :	Edge down to precise lens shape.	

*ALL SWISSCOAT SupremeCOAT™ products (Rx and Stock lens) must strictly follow the above Edging Instruction.